


American DJ®

User Instructions

GALACTIC STAR 19C™



Caution! Always disconnect from main power before servicing unit.

Thank you for purchasing this *American DJ*® product. For your convenience there is no assembly required. Please read the following instructions before installing or using your new unit.

Operating Instructions:

The Galactic Star 19C™ is a 19" Rackmount controller which allows you to control the chase pattern of the Galactic Star/ GR™, Galactic Star™. You can Mode select between Auto, Music, or Manual Chase. When you are in Auto Mode you can adjust the speed of steps, from 1 per second to 5 per second, by Adjusting the Speed ^Speed v buttons. When you are in Music Chase Mode you can adjust the AUDIO sensitivity control. When you are in Manual mode there is a STEP Button which allows you to tap when you want a step but it will only change when you tap the STEP button . The Galactic Star 19C™ also has Blackout (STANDBY).

GALACTIC STAR 19C™

- Manual Step change
- Can control 24 heads
- Sensivity control
 - Auto Speed
- Sound Activation
 - Music control
 - Black out
- 1.75" x 19" x 2.25"
 - 2 lbs.

For service, contact your *American DJ*® dealer.