

ADJ INNO POCKET ROLL - DMX TRAITS

CHANNEL	DMX VALUES	FUNCTION
1	000 - 255	<i>Pan</i>
2		<i>Tilt</i>
	000 - 009	Stop
	010 - 120	Clockwise Roll, slow to fast
	121 - 134	Stop
	135 - 245	Counter-Clockwise Roll, slow to fast
	246 - 255	Stop
3		<i>Strobe</i>
	000 - 007	Blackout
	008 - 015	Open
	016 - 131	Strobing, slow to fast
	132 - 139	Open
	140 - 181	Slow Open, Fast Close
	182 - 189	Open
	190 - 231	Fast Open, Slow Close
	232 - 239	Open
	240 - 247	Random Strobe
	248 - 255	Open
4		<i>Color Wheel</i>
	000 - 007	Open
	008 - 014	Gobo 1 - Yellow
	015 - 021	Gobo 2 - Red
	022 - 028	Gobo 3 - Green
	029 - 035	Gobo 4 - Blue
	036 - 042	Gobo 5 - RGB
	043 - 049	Gobo 6 - UV
	050 - 056	Gobo 7 - Light Blue
	057 - 063	Gobo 8 - UV and Light Blue
	064 - 071	Open Shake
	072 - 078	Gobo 1 Shake
	079 - 085	Gobo 2 Shake
	086 - 092	Gobo 3 Shake
	093 - 099	Gobo 4 Shake
	100 - 106	Gobo 5 Shake
	107 - 113	Gobo 6 Shake
	114 - 120	Gobo 7 Shake
	121 - 127	Gobo 8 Shake
	128 - 255	Gobo Wheel Rotation, slow to fast
CONTINUED ON NEXT PAGE		

ADJ INNO POCKET ROLL - DMX TRAITS

CHANNEL	DMX VALUES	FUNCTION
5	000 - 255	<i>Master Dimmer</i> , 0% to 100%
6		<i>Dimmer Mode</i>
	000 - 020	Standard
	021 - 040	Stage
	041 - 060	TV
	061 - 080	Architectural
	081 - 100	Theatre
	101 - 255	Default Dimmer Setting